

Daily use and maintenance
instructions for mechanical keyboards


Structurally speaking, the mechanical keyboard is just a switch under each button. Its fears dust, beverages, oil and water from the structure itself. In daily use, you should keep these substances from falling into the keyboard which may cause key failure or make damage to the circuit board.












1. Precautions for dust: Avoid soot or other dust falling into the keyboard. If soot or other dust enters, the best way to deal with it is to remove the keycap, then clean it up by sucking while brushing with a vacuum cleaner and a brush. Never flip and tap the keyboard without removing the keycap, which will cause more dust to enter the shaft and damage the shaft.
2. Ways to use the keyboard cleaning mud: Do not press the entire cleaning mud directly onto the keyboard. The correct way to use it is to clean the dust on the surface of the keycap with a slight pressure, then pull out the keycap and take a small piece of cleaning mud and knead it into a small ball. Roll it in the gap of the shaft body to clean the dust.
3. Precautions for keyboard liquid input: If any kind of fluid falls into the keyboard, please power off the keyboard quickly. At the same time, make a hand-made drying box with a hair dryer and a large carton, then put the whole keyboard into the box for fast drying for about 2 hours (avoid blowing the hair dryer directly to the keyboard at close range, otherwise the keyboard shell will be deformed due to high temperature) When fluid other than clean water invades, if there is a problem with the shaft after drying, please contact the after-sales service as soon as possible.


Note: The final interpretation right of this product belongs to GANSS brand



GANSS GS3104T
2.4G · Bluetooth · RGB

The Switch is on the keyboard ‘s back	 BT Wired 2.4G	2.4G:Switch to 2.4G,Plug the receiver on the back of the keyboard into the computer
		Bluetooth:Switch to BT,Match according to the method described below

Multimedia Func Keys		Win	Mac		Win	Mac
	FN+F1	Computer		FN+F7	Play/Pause	
	FN+F2	Browser		FN+F8	Stop	
	FN+F3	Email		FN+F9	Volume+	
	FN+F4	Player		FN+F10	Volume-	
	FN+F5	Previous		FN+F11	Mute	
	FN+F6	Next		FN+F12	Calculator	

Basic Func Keys	FN+Caps	Hold down for 3s-Switch the position of caps and left Ctrl	
	FN+Win_L	Lock/Unlock WIN key	
	FN+A	Hold down for 3s-Windows system support(Default)	
	FN+S	Hold down for 3s-MAC system support	
	FN+Tab	On/off the macro functions in the driver	
			Turn anticlockwise:Volume- Press:Mute/Resume Volume Turn clockwise:Volume+
	FN+Space	Hold down for 5s - Reset to factory settings	

Note: when using different combination keys, indicating lights will have different frequency flashing hints.

Bluetooth Func Keys	FN+Q	Switch to device 1	FN+W	Switch to device 2
	FN+E	Switch to device 3	FN+R	Switch to device 4
	FN+T	Switch to device 5		
	FN+P	Hold down for 3s -Bluetooth pairing		

Instructions of Bluetooth Paring:
If you want to save the current Bluetooth device to be matched to key Q (Bluetooth device 1),first confirm that the keyboard is in Bluetooth mode,press and hold the FN key,then press the Q key to switch to Bluetooth device 1(the indicator flashes briefly),and then press and hold the FN key and P key for Bluetooth code matching (the indicator flashes continuously),Then operate the Bluetooth function of the current device(or tablet and other devices)to find the Bluetooth keyboard and click to pair.Next,please wait patiently.This process takes several seconds (the length of time is related to the performance of the device).
After successful pairing,the flashing indicator light will go out automatically,and the keyboard can be used normally.
Repeat the above operation to save up to 5 Bluetooth device information,and switch with FN+Q/W/E/R/T.

Backlights Func Keys	FN+ (1-7)	Multiple backlight modes You can use FN + 7 to change the color of RGB light	FN+[Light mode adjustment of knob
	FN+ (8-0)	3 Custom mode (depends on the model)	
	FN+ ↓	Backlights weaken	FN+] Light color adjustment of knob
	FN+ ↑	Backlights brighten	
	FN+←	Backlights slower	
	FN+→	Backlights faster	

How to use custom mode:
If you want to set the custom lighting effect of 8 keys, long press FN + 8 for 3 seconds to enter the lighting recording mode. At this time, the keyboard indicator will flash. Then click the key you want to set. After setting, long press FN + 8 again for 3 seconds, the indicator will stop flashing, and the lighting recording is over. Next time, you can directly use FN + 8 to call up the previously set custom lighting effect.

Reminder(If your keyboard has wireless function)

Lithium battery products:
When the battery voltage is too low, the indicator will flash slowly to remind,Charge the battery,please.If use while charging, the charging efficiency is very low.
low battery:Press the FN key,The light of Key-ESC will Show red, in wireless mode.
Charging:Press the FN key,The light of Key-ESC will Show Blue, in wireless mode.
Full battery:Press the FN key,The light of Key-ESC will Show green, in wireless mode.

Welcome to the official website to check whether your product has the corresponding driver, so that you can use the product more conveniently.